
## **Clearance and Creepage Distance**

The following picture explains how to measure the distance between two metal parts:



## Rule

Clearance is the "line of sight" distance. The creepage path follows the contour of the groove.

Phone: 514 694-9136 Fax: 514 694-0956

Toll Free: 1 800 724-2928 (US and Canada)